



SNO-KONE

MACHINE OPERATION

(Children are not allowed to operate machines!)

1. Place Machine on clean, level surface.
2. Plug in power cord into the appropriate electrical outlet.
3. Turn on the motor and the display lights. Motor will come to full speed in a minute or so.
4. Fill the gooseneck to within an inch of the top with ice cubes or block ice (no larger than 3 to 4 inches in size. 3-4" pieces produce the best snow.
5. Press the pusher handle down against the ice in the gooseneck.
6. Apply firm and even pressure to make the best snow.
Practice will allow you to gauge when to stop pressing.
7. Using syrup dispenser, squirt syrup over ice. 1 to 3 squirts is usually enough.

Notes:

- You may find that you need to relieve the pressure two or three times in a cycle. Over-pressing will stall the motor. In this case, simply relieve the pressure and try again. Too much pressure will result in snow that is coarse. Too little pressure will make the snow mushy.
- Under normal operating conditions, the motor will become very warm.
A surface temperature of 150F degrees is normal.

Caution: Never allow any foreign or metallic objects around the shaver area.
Never stick hand into shaver area.