



Chafing Dish

Instructions

1. Fill water pan with 1"-2" of hot water.
2. Use only sterno type fuel. NEVER use lighter fluid, gasoline, or kerosene.
3. Do not put chafer unit on a hot stove or over an open flame.
4. The stainless food pan can be used for cooking and may be placed in oven.
5. Only light sterno when ware is in the water pan.
6. Light sterno approximately 20 minutes before food pan is placed in chafer unit.
7. Cover chafer once sterno is lit.
8. The top of the sterno can be opened and closed to adjust sterno flame.
9. When sterno is empty – BE CAREFUL – Can is very hot – Remove carefully.